

GATE ACCESS TRANSPONDER INSTRUCTIONS

- To determine the best location to place the transponder on the windshield:
 - Pull the front of the car as close to the gate arm as possible.
 - Holding the Transponder (starting at the lower left-hand corner of the inside of the windshield) slowly move the transponder up the windshield. At the point where the gate opens that would be the place to attach the transponder to the windshield.
 - If that does not work, try placing, transponders behind the rearview mirror. However, if you have an EZpass or SunPass, these devices may interfere with the transmission.
 - If the transponder does not transmit from inside of the car:
 - Roll the window down on the driver's side and hold it out of the window pointing it at the reader.
 - Do not wave the transponder at the reader; just hold it for 15 seconds giving the reader time to read it.
 - The readers are slow to react; it takes approximately 15 seconds to activate the gates.
- The effectiveness of the transponder depends on:
 - The height of the car – how tall, how short, slant of the windshield
 - The reader location at each gate
 - The materials used to tint the windshield which may interfere with the transponder transmission and cause it to not work.
 - The presence of an EZpass or SunPass device may also interfere with transmission.
- Additional information:
 - The gate transponders will activate all gates for all phases of Solivita, including BelleViana and Venezia.
 - The gate transponders do not use batteries; they use a radio signal similar to a garage door opener.
 - Fee for a lost or damaged gate transponder replacement: \$40

If you have difficulties please return the Transponder to the Membership office in the Administration Building or eMail SolivitaMembership@AAMFL.com.